

RTX2254

Bluetooth RF Tester

Stand-alone Unit



User Manual

V0216.3
MVC 2020.04.15

General

Information contained in this document is subject to change without notice. RTX A/S makes no warranty of any kind regarding to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

RTX A/S shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishings, performance, or use of this material.

Warranty

This instrument is warranted against defects in material and workmanship for a period of one year from date of shipment. During the warranty period, RTX A/S will at its option, either repair or replace products, which prove to be defective. For warranty service or repair, this product must be returned to a service facility designated by RTX A/S. The Buyer shall prepay shipping charges to RTX A/S and RTX A/S shall pay shipping charges, duties, and taxes for products returned to RTX A/S from another country.

RTX A/S warrants that its software and firmware designated by RTX A/S for use with an instrument will execute its programming instructions when properly installed on that instrument.

RTX A/S does not warrant that the operation of the instrument or firmware will be uninterrupted or error-free.

Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED.

RTX A/S SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

General information

This document and the information contained herein, is property of RTX A/S, Denmark. Unauthorized copying is not allowed. The information in this document is believed to be correct at the time of writing. RTX A/S reserves the right at any time to change said content, circuitry and specifications.

The general safety precautions, according to the RTX2254 User Manual, must be observed during all phases of operation. RTX A/S assumes no liability for the user's/customer's failure to comply with these requirements.

The purpose of the document is to provide guidance to users of the RTX2254 Bluetooth RF Test. The User Manual describes general functions of the tester and describes the use of the Windows® based interface, as well as interfacing with a production application program.

For further information about programming of the RTX2254 Bluetooth RF tester, please refer to the "Quick Guide" document

Documentation Information

This User Manual contains essential items of information needed for general-purpose use of the test equipment along with a detailed description for high throughput production purposes.

In this document, you will find valuable information on how to unpack, install and operate your RTX2254 Bluetooth RF tester using the supplied PC application or a test program using the available programming API.

The User Manual provides programming guidance to users of the RTX2254 Bluetooth RF tester who would like to write their own test programs.

Furthermore, you also find information on how to use the provided RTX2254 DLL file in a sample application to show with a few examples on how to use the DLL function calls in your source code are outlined.

However, please note that the examples and code fragments are included for informational reasons only and should only be used as a guidance to ease test program development. It is therefore strongly emphasized here that RTX A/S takes no responsibility for debugging and verification of the actual test program developed by the user/customer.

Safety Information

General

The following general safety precautions must be observed during all phases of operation and service of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. RTX A/S assumes no liability for the customer's failure to comply with these requirements.



DO NOT operate the product in an explosive atmosphere or in the presence of flammable gasses or fumes.



DO NOT use repaired fuses or short-circuited fuse holders: For continued protection against fire, replace the line fuse(s) only with fuse(s) of the same voltage and current rating and type.



DO NOT perform procedures involving cover or shield removal unless you are qualified to do so – it is therefore strongly emphasized here that operating personnel must not remove equipment covers or shields. Procedures involving the removal of covers and shields are for use by service-trained personnel at RTX A/S only.

Electrostatic Discharge

Electrostatic discharge (ESD) can damage electronic test equipment. Working with electronic components or test equipment should always be performed at a static-safe place.

High Voltage

Some power supplies can generate high voltage, which can damage any of the ports of the unit.

To prevent damage to the RTX2254 Bluetooth RF tester please make sure that the device is properly earthed. Connect the RF cable path before applying DC power to the test device. Be careful when connecting RF connectors, i.e. avoid touching any unearthed metal with the centre core.

TABLE OF CONTENTS

1	INTRODUCTION	8
2	WORD AND ABBREVIATION LIST	9
3	START THE APPLICATION	10
4	TAB MENU OVERVIEW	11
5	MAIN TAB	12
5.1	Setup	14
5.1.1	Measure Mode	15
5.1.2	PER Test - Packet Parameters	15
5.1.2.1	Number of Packets	15
5.1.2.2	Payload Length	15
5.1.2.3	Payload Type	15
5.1.2.4	Gen. Power [dBm]	16
5.1.3	Select RF Physical Channels	16
5.1.4	Open Interface	17
5.1.5	DUT Port Selection	17
5.1.5.1	RF Select	17
5.1.5.2	Interface Select	17
5.1.6	Settings	17
5.1.7	Select Tests to Run	18
5.1.8	Test Result	18
5.1.9	Test Run	19
5.1.9.1	Start / Pause / Stop	19
5.1.9.2	Loop Test Numbers	19
5.1.9.3	Test Delay	19
5.1.10	Test Status	20
5.1.10.1	Current Channel	20
5.1.10.2	Cable Loss	20
5.1.10.3	Test Completed	20
5.1.10.4	Test Limit Errors	20
5.1.10.5	Time Out Errors	20
5.1.10.6	Channel Test Time	20
5.1.10.7	Total Test Time	21
6	DUT TAB	22
6.1	DUT RF Setup	23
6.1.1	Tx – Mode	23
6.1.1.1	Channel	23
6.1.1.2	Payload Length	23
6.1.1.3	Payload Type	23
6.1.2	Rx - Mode	24
6.1.2.1	Channel	24
6.1.2.2	Received Packets	24
6.2	DUT Port Selection	25
6.2.1.1	RF Select	25
6.2.1.2	Interface Select	25
6.3	DUT Status	25
6.3.1	Reset RF Mode	25
6.3.2	Reset DUT	25
6.4	Start Tx Burst Mode	26

6.5	Start Rx Burst Mode	27
7	TESTER TAB	29
7.1	Tester Setup – Burst Mode	30
7.1.1	Tx – Mode	30
7.1.1.1	Channel	30
7.1.1.2	Gen. Power [dBm]	31
7.1.1.3	Payload Length	31
7.1.1.4	Payload Type	31
7.1.1.5	Number of Packets	31
7.1.1.6	Packets Sent	31
7.1.2	Rx - Mode	32
7.1.2.1	Channel	32
7.1.2.2	Received Packets	32
7.2	Tester Setup – Continuous Wave	33
7.2.1	Tx – Mode	33
7.2.1.1	Channel	33
7.2.1.2	Tx – Set Attenuation	34
7.3	Tester RF Input Power	35
7.4	Tester Analyzer Mode	36
7.5	Tester Status	37
7.5.1	Reset RF Mode	37
7.5.2	Reset Tester	37
7.5.3	Reset Ana+Gen	37
7.6	Start Tx Burst Mode	38
7.7	Start Rx Burst Mode	39
8	SYSTEM TAB	41
8.1	System Status	41
8.2	Manufacture Info	41
8.3	System Option License	42
8.4	Internal Temperature	42
8.5	Firmware Update	43
8.6	Manual Firmware Update	44
8.6.1	Tester Firmware	44
8.6.2	Analyzer Firmware	44
9	MEASURE LOGS TAB	45
10	SETTINGS TAB	47
10.1	How to find COM ports on Windows PC	48
10.2	Tester Interface	48
10.2.1	Tester - RTX BLE Tester Interface	48
10.2.2	Generator - RTX BLE Generator Interface	49
10.2.3	Analyzer - RTX BLE Analyzer Interface	49
10.3	DUT interface	50
10.3.1	Automatically Setup of DUT COM ports	51
10.3.2	Manually Setup of DUT COM ports	54
11	CONFIGURATION TAB	56
11.1	Test Mode	57

11.2	Test Result Limits	57
11.3	DUT Configuration	57
11.3.1	Direct Test Mode	57
11.3.2	Advertising Mode	58
12	HOW TO SETUP AUTOMATED TESTING - DIRECT TEST MODE	59
12.1	DUT Test Limits	59
12.2	DUT Test Setup	60
12.3	Starting the DUT Test	61
12.3.1	DUT - Within Test Limits	62
12.3.2	DUT - Outside of the Test Limits	63
13	HOW TO SETUP AUTOMATED TESTING - ADVERTISING MODE	64
13.1	DUT Test Limits	64
13.2	DUT Test Setup	65
13.3	Starting the DUT Test	67
13.3.1	DUT - Within Test Limits	68
13.3.2	DUT - Outside of the Test Limits	69
14	HOW TO SETUP MANUAL TESTING	70
14.1	DUT Tab	70
14.1.1	For example, "Test DUT Tx power"	70
14.2	Tester Tab	71
14.2.1	For example, "Test DUT Tx power"	71
15	HOW TO RUN A RX SENSITIVITY TEST	72
16	HARDWARE DESCRIPTION	74
16.1	Test Interfaces	74
16.1.1	DUT RF Inputs	75
16.1.2	DUT Communication Interfaces	75
16.1.2.1	UART0 and UART1 Connector Pinout	75
16.1.2.2	2-Wire	76
16.1.2.3	USB0 and USB1 Connector Pinout	76
16.2	Test Protocols	76
17	TEST LIMITATIONS	77
17.1	Generator Output Power	77
17.2	Frequency Offset	78
17.3	PER Test	79
18	DEMO APPLICATION	80
18.1	Settings	80
18.2	Running the Demo Application	81
19	FREQUENTLY ASKED QUESTIONS	83

1 Introduction

The RTX2254 Bluetooth RF tester is a highly-optimized, automated test solution for calibration and functional test in the production of wireless Bluetooth Low Energy (BLE) devices. It supports Direct Test Mode (DTM) and optional Advertising Mode (ADV).

This User Manual will describe the different features and options which are available with the RTX2254 Bluetooth RF tester stand-alone unit, the configuration and some test scenarios using the RTX2254 application.

Please follow the instructions in the "RTX2254 Quick Installation Guide" on how to install the RTX2254 software and setup your RTX2254 tester.

The RTX2254 application uses the available API, i.e. it can be integrated into other test systems which can interface to Visual Studio C++ API's (standard DLL and header files).

The RTX2254 and RTX2300 BLE bundle API is described in the "BtTstInterface_V<version number>.pdf" document.



RTX2254 with DUT on USB

Note that

RTX2254 is available as a single ported tester for one DUT (RTX no. 95101347) or as a dual ported tester for two DUTs (RTX no. 95101348).

Advertising Mode is an option.

2 Word and Abbreviation List

The following words and abbreviations are used in this document:

- 2-Wire Bluetooth SIG specified test protocol where only Tx, Rx and GND is used and 16-bit commands and events
- ADV Advertising Mode, see the Bluetooth Low Energy (BLE) specification for a description of BLE advertising
- API Application programming interface
- BER Bit Error Rate
- BLE Bluetooth low energy
- BT Bluetooth
- BTLE Bluetooth low energy
- COM Serial communication port referred to by a number
- CW Continuous Waveform
- DLL Dynamic Link Library
- Driver SW that interfaces to a HW unit
- DTM Direct Test Mode, see the Bluetooth test specification
- DUT Device Under Test
- EAI Enterprise Application Integration
- ESD Electro-Static Discharge
- GND Ground
- GUI Graphical User Interface
- HCI Host Controller Interface
- HW Hardware
- ID Identification
- IRR Inquiry response rate
- ISM Industrial Scientific and Medical
- LL Link Layer
- LQ Link Quality
- MAC Media access control
- PC Personal Computer
- PDU Protocol data unit
- PER Packet Error Rate
- Pop-Up A smaller frame shown in windows
- PPM Part Per Million
- RF Radio frequency
- RS232 Serial port with +-12V signaling
- RSS Received Signal Strength
- RSSI Received signal strength indicator
- RTX2300 Test system with shielding, fixture and test HW
- Rx Receive
- SIG Special interest group for BT
- SW Software (Programs)
- TI Texas Instruments – Chip manufacturer
- Tx Transmission
- UART Serial port with logic level signaling (0-5V)
- USB Universal Serial Bus

3 Start the Application

After following the RTX2254 Quick Guide, you are now ready to start.

Make sure that the RTX2254 RF Bluetooth Tester is connected to your PC with the USB cable and power is on.

You can start the “**RTX2254 Bluetooth RF tester**” application by pressing the Windows start button and selecting:

“Start → All programs → RTX → RTX2254 Bluetooth RF tester → V<version number> → RTX2254 Bluetooth RF tester – <version number>”.

Or by clicking on the short cut on the desktop if the ‘Short cut’ option was enabled during installation.

This description will use Direct Test Mode to show how to operate the RTX2254 Bluetooth RF tester. Advertising Mode is very similar and will be described in section 13 How to Setup Automated Testing - Advertising Mode.

Start-up screen:




4 Tab Menu Overview

The RTX2254 Bluetooth RF tester application has the following tab menus with different pages to setup and control the tester:

- **[Main]** Different production tests which can be performed:
 - Frequency Offset measurement
 - Output Power measurement
 - Packet Error Test (PER)
- **[DUT]** Manual control of DUT part
- **[Tester]** Manual control of tester part
- **[System]** Information about the tester, e.g. firmware version
- **[Measure logs]** Log for the tests performed under the **[Main]** page
- **[Settings]** System setup, e.g. tester and DUT interface
- **[Configuration]** System configuration of tester limits and DUT setup compensations

First startup with default settings:



Please note that:


The window can be resized or maximized depending on your screen resolution.

At startup, the application will be resized to the size selected when the application was terminated.

5 Main Tab

On the **[Main]** page, you can perform the different tests with the settings suited for your DUT and your requirements:

- **Frequency Offset Measurement** Measures the channel frequency offset. This can be done on burst or CW signals.
- **Output Power Measurement** Measures the DUT output power.
- **Packet Error Test (PER)** Performs a packet error rate test on the DUT.




Info & error messages are shown here

Interface status with DUT address – all must be green

The **[Main]** page is divided into the following sub sections:

- **[Setup]** Setup of parameters to use in the test. Set the parameters suited for your test and DUT info. Click save.
- **[Select Tests to Run]** Enable the test measurements to perform. Check a test box to enable it.
- **[Start Result]** The overall status of the last test run.
- **[Test Run]** Start/pause/stop the test.
- **[Test Status]** Status information for the test run.




Please note that:

Window is resized to the previous stored setting and the RTX2254 tester and DUT are connected and with default test parameters.

5.1 Setup

On the **[Main]** page, you can setup the following parameters to use during the test:



The screenshot shows the 'Setup' interface with the following sections:

- Measure Mode:** A dropdown menu set to 'DTM Burst'.
- PER Test - Packet Parameters:** Includes 'No. of Packets' (500), 'Payload Length' (25), 'Payload Type' (ALTBITS_10101010), and 'Gen. Power [dBm]' (-41).
- Open Interface:** A checked checkbox for 'DUT' and a 'Reset DUT' button.
- DUT Port Selection:** Two dropdown menus for 'DUT0 RF Select' and 'DUT0 USB', with a 'Select' button below them.
- Settings:** A 'Save' button and a note: 'Click "Save" to store setup'.
- Select RF Physical Channels:** Three checkboxes for 'RF Channel 1', 'RF Channel 2', and 'RF Channel 3', each with a numeric input field (0, 19, and 39 respectively).
- Channel Mapping:** A table showing channel mappings:

Phy	LL	MHz
Ch. 0	(37)	= 2402
Ch. 1	(0)	= 2404
Ch. 19	(17)	= 2440
Ch. 39	(39)	= 2480
- DUT Info:** Displays 'BT Address: 0x84DD20C503AA' and a time field '- [ms]'.

Overview:

- **[Measure Mode]** Select signal type to use: **[DTM Burst]** or **[DTM CW]** (Continuous Wave). Default is **[DTM Burst]**.
- **[PER Test – Packet Parameters]** The parameters to use when running the PER test. See more details below.
- **[Select RF Physical Channels]** Enable up to 3 channels (RF1, RF2 and RF3). Select the channels to use for testing.
- **[Open Interface]** Check **[DUT]** box to open the DUT interface. If checked it will automatically open on next startup.
- **[DUT Port Selection]** Select the RF port and communication port to use with the DUT.
- **[Settings]** Click **[Save]** button to store the settings.
- **[DUT Info]** The Bluetooth address of the DUT.

Please note that:

You must click **[Save]** to store the system settings before selecting another tab page. If you leave the **[Main]** page without saving the settings, the last stored settings will be restored when selecting to the **[Main]** page again.

5.1.1 Measure Mode

Select signal type to use **[DTM Burst]** or **[DTM CW]** (Continuous Wave).

Please note that:

CW is chip vendor/customer specific and must be implemented by customer in the DUT API.

5.1.2 PER Test - Packet Parameters

The following BLE packets parameters are supported by the RTX2254 Bluetooth RF tester:

5.1.2.1 Number of Packets

[No. of Packets], the enter number of packets to send. Valid range between 100-65535.

5.1.2.2 Payload Length

[Payload Length], enter the number of bytes to send as payload in each packet. Valid range between 0-37.

5.1.2.3 Payload Type

[Payload Type], select one of the following BLE payload/packet types, defined by Bluetooth SIG, to use.

Direct Test Mode:

HCI Protocol:

0x00 Pseudo-Random bit sequence 9 (PRBS9)
0x01 Pattern of alternating bits '11110000'
0x02 Pattern of alternating bits '10101010'
0x03 Pseudo-Random bit sequence 15
0x04 Pattern of All '1' bits
0x05 Pattern of All '0' bits
0x06 Pattern of alternating bits '00001111'
0x07 Pattern of alternating bits '0101'

2-Wire Protocol:

0x00 Pseudo-Random bit sequence 9 (PRBS9)
0x01 Pattern of alternating bits '11110000'
0x02 Pattern of alternating bits '10101010'
0x03 Vendor Specific

Advertising Mode:

0x00 NO_SCAN_RESPONSE
0x01 SCAN_RESPONSE

Refer to section 13.2 DUT Test Setup for more details.

5.1.2.4 Gen. Power [dBm]

[Gen. Power [dBm]], the generator power level used by the RTX2254 tester when transmitting the packets. Valid range between -40 to -100 dBm.

Please note that:

The generator power level range is compensated with the specified cable loss. However, it cannot go above -40 dBm, e.g. -40 dBm and cable loss = 1 dBm should give -39 dBm. This is not possible, and tester shows -41 dBm. In example, generator set to -50 dBm and cable loss = 1 dBm. Internally generator power is -49 dBm to give -50 dBm to the DUT.

5.1.3 Select RF Physical Channels

[Select RF Physical Channels], select the RF channel to use with test loop 1, 2 and 3, e.g. 0, 19 and 39.

Check the **[RF Channel x]** box to enable it in the test loop.

For Direct Test Mode, the below 40 RF channels are supported. For Advertising Mode, the channels are locked to channels 0, 12 and 39:

RF Channel	Frequency
0	2402 MHz
1	2404 MHz
2	2406 MHz
3	2408 MHz
4	2410 MHz
5	2412 MHz
6	2414 MHz
7	2416 MHz
8	2418 MHz
9	2420 MHz
10	2422 MHz
11	2424 MHz
12	2426 MHz
13	2428 MHz
14	2430 MHz
15	2432 MHz
16	2434 MHz
17	2436 MHz
18	2438 MHz
19	2440 MHz

RF Channel	Frequency
20	2442 MHz
21	2444 MHz
22	2446 MHz
23	2448 MHz
24	2450 MHz
25	2452 MHz
26	2454 MHz
27	2456 MHz
28	2458 MHz
29	2460 MHz
30	2462 MHz
31	2464 MHz
32	2466 MHz
33	2468 MHz
34	2470 MHz
35	2472 MHz
36	2474 MHz
37	2476 MHz
38	2478 MHz
39	2480 MHz

Please note that:

The channel number refers to the physical frequency and not the link layer (LL) channel.

5.1.4 Open Interface

[Open Interface], check **[DUT]** box to open the DUT interface if not already opened manually. If checked and saved, the DUT interface will be automatically opened when you go to the **[Main]** page. It can also be used to temporarily close the DUT interface by removed in the check in the **[DUT]** box.

Click **[Reset DUT]** to send a reset command to the DUT.


5.1.5 DUT Port Selection

Select the RF port and communication port to use with the DUT.

5.1.5.1 RF Select

Select the RF port to use:

- **[DUT0 RF Select]**
- **[DUT1 RF Select]** (Dual port only)



5.1.5.2 Interface Select

Select the communication port to use:

- **[DUT0 UART]**
- **[DUT1 UART]** (Dual port version only)
- **[DUT0 USB]**
- **[DUT1 USB]** (Dual port version only)

Click **[Select]**, when you have selected the RF port and communication port to use.

Please note that:

RTX2254 is available as a single ported tester for one DUT (RTX no. 95101347) or as a dual ported tester for two DUTs (RTX no. 95101348).

The **[Interface Select]** field is not available for Advertising Mode.

5.1.6 Settings

Click **[Save]** button to store the settings entered.

5.1.7 Select Tests to Run

[Select Tests to Run], enable the test measurements to perform:

- | | |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ol style="list-style-type: none"> 1) DUT Frequency Offset 2) DUT Tx Output Power 3) PER – Packet Error Rate <p>Rx Sensitivity Test</p> | <p>Measures the frequency offset on selected channels.</p> <p>Measures the Tx output power on selected channels.</p> <p>Performs a packet error rate test on selected channels.</p> <p>A sub test to run together with the PER test. The tester will automatically adjust the generator power to find the DUT’s Rx sensitivity level for the packet error rate level specified.</p> |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Check the test box to enable it in the test run.

Please note that:


Refer to section 15 How to Run a Rx Sensitivity Test for more details on how to setup and run a Rx Sensitivity test.

5.1.8 Test Result

[Test Result], shows the overall result from the test run.

5.1.9 Test Run

Here you can specify how many test loops you want to run and if a delay is required between the test loops.



5.1.9.1 Start / Pause / Stop

Step 1:

- **[Start]** Click **[Start]** to start the test.
- **[Stop]** No function – no test is running.

Step 2:

- **[Running]** No function – test is already running.
- **[Pause]** Click **[Pause]** to temporary pause the running test.

Step 3:

- **[Continue]** Click **[Continue]** to continue a paused test.
- **[Stop]** Click **[Stop]** to stop the test.

5.1.9.2 Loop Test Numbers

[Loop Test No.], enter how many test loops to run on DUT.

5.1.9.3 Test Delay

Set **[Test Delay]** to add a short delay between each channel test. Delay is in ms. Valid range is 0 to 30.000 ms.

Remember to setup the DUT testing requirements (limits). Refer to chapter 11 Configuration.

5.1.10 Test Status

The **[Test Status]** sub section is updated during the test run:

Test Status			
Current Channel	Cable Loss	Test Completed	Test Limit Errors
0 Ch. 2402 MHz	1.00	0	Offset 0
DUT packet interval configuration setting [ms] 1			Tx Pwr 0
			PER 0
			Pkt. Int. 0
		Time Out Errors	Ch. Test Time [ms]
		0	Last 0.00
			Avg. 0.00
			Total Test Time [s] 0.000

5.1.10.1 Current Channel

[Current Channel], shows the current channel tested as the physical channel number and the frequency in MHz.

5.1.10.2 Cable Loss

[Cable Loss], shows the current added cable loss. Refer to chapter 11 Configuration.

5.1.10.3 Test Completed

[Test Completed], shows the number of test loops completed including any faulty test loops.

5.1.10.4 Test Limit Errors

[Test Limit Errors], shows the number of test results outside the test limits set by user. Refer to chapter 11 Configuration.

Status error count for:

- **[Offset]** DUT Frequency Offset
- **[Tx Pwr]** DUT Tx Output Power
- **[PER]** Packet Error Rate
- **[Pkt. Int.]** Packet Interval (only used in Advertising Mode)

5.1.10.5 Time Out Errors

[Time Out Errors], shows the number of test loops which failed due to time out in the communication to tester or DUT.

5.1.10.6 Channel Test Time

[Ch. Test Time], the test time for one RF Channel:

- **[Last]** Time for last finished channel test
- **[Avg.]** The average channel test time for all completed test loops.

5.1.10.7 Total Test Time

[Total Test Time], the total time running the specified test loops.

This include any user added **[Test Delay]** time.


6 DUT Tab

On the **[DUT]** page, you can control the DUT manually. This page in conjunction with the **[Tester]** page allow you to run manual tests. The **[DUT]** tab is not available for Advertising Mode.

This means that you can start a DUT test in Tx or Rx burst mode, e.g. if you start a DUT Tx burst test, you must first start a Rx burst test on the **[Tester]** page.

Overview:

- **[DUT RF Setup]** Setup the test to perform.
- **[DUT Port Selection]** Select the RF port and communication port to use with the DUT.
- **[DUT Status]** The state of the DUT and reset RF mode and reset DUT options.



Please note that:

The DUT port selection is also available on the **[Main]** page.

6.1 DUT RF Setup

In this sub section, you can setup a DUT transmission (Tx) or receive (Rx) test to perform in burst mode.

6.1.1 Tx – Mode

Use the **[Tx – Mode]** sub section to perform a transmit test.

Click **[Start]** to start the test.

Click **[Stop]** to stop the test again.

Please note that:

The DUT Tx power used is the default by chip vendor. Use a vendor specific HCI command to set the Tx power as required. This can be done from vendor/third party tool.

The number of packets to send from DUT is not supported in Bluetooth DTM radio test.

6.1.1.1 Channel

[Channel], enter the physical RF channel to use in the test. Valid range 0-39. Refer to section 5.1.3 Select RF Physical Channels for more details.

6.1.1.2 Payload Length

[Payload Length], enter the number of bytes to send as payload in each packet. Valid range between 0-37.

6.1.1.3 Payload Type

[Payload Type], select one of the following BLE payload/packet types, defined by Bluetooth SIG, to use.

Direct Test Mode:

HCI Protocol:

- 0x00 Pseudo-Random bit sequence 9 (PRBS9)
- 0x01 Pattern of alternating bits '11110000'
- 0x02 Pattern of alternating bits '10101010'
- 0x03 Pseudo-Random bit sequence 15
- 0x04 Pattern of All '1' bits
- 0x05 Pattern of All '0' bits
- 0x06 Pattern of alternating bits '00001111'
- 0x07 Pattern of alternating bits '0101'

2-Wire Protocol:

- 0x00 Pseudo-Random bit sequence 9 (PRBS9)
- 0x01 Pattern of alternating bits '11110000'
- 0x02 Pattern of alternating bits '10101010'
- 0x03 Vendor Specific

6.1.2 Rx - Mode

Use the **[Rx - Mode]** sub section to perform a receive test.

Click **[Start]** to start the test.

Click **[Stop]** to stop the test again.

6.1.2.1 Channel


[Channel], select the physical RF channel to use in the test. Valid range 0-39. Refer to section 5.1.3 Select RF Physical Channels for more details.

6.1.2.2 Received Packets

[Received Packets], will be updated with the number of packets received when **[Stop]** is pressed.

6.2 DUT Port Selection

Select the RF port and communication port to use with the DUT.



6.2.1.1 RF Select

Select the RF port to use:

- **[DUT0 RF Select]**
- **[DUT1 RF Select]** (Dual port only)

6.2.1.2 Interface Select

Select the communication port to use:

- **[DUT0 UART]**
- **[DUT1 UART]** (Dual port only)
- **[DUT0 USB]**
- **[DUT1 USB]** (Dual port only)

Click **[Select]**, when you have selected the RF port and communication port to use.

Please note that:

The **[DUT Port Selection]** settings are not stored and will be set to the settings stored under the **[Main]** page if RTX2254 application is restarted. If the **[DUT Port Selection]** is changed on the **[DUT]** page, you must click **[Select]** on the **[Main]** page to set the DUT settings again.

RTX2254 is available as a single ported tester for one DUT (RTX no. 95101347) or as a dual ported tester for two DUTs (RTX no. 95101348).

6.3 DUT Status

In the **[DUT Status]**, the current state of the DUT is shown, i.e. which function has been selected.



6.3.1 Reset RF Mode

Click **[Reset RF Mode]** to reset the application internal mode. The DUT is not reset.

This can be used if the DUT is power cycled and you want to restart the test.

6.3.2 Reset DUT

Click **[Reset DUT]** sends a reset command to the DUT to reset its internal state.

If this is not possible, power cycle the DUT.

6.4 Start Tx Burst Mode


In **[Tx – Mode]** sub section, click **[Start]** to let the DUT start transmission of burst on the specified RF channel (Ch 0 = 2402 MHz) using the specified payload length and type.

The **[DUT Status]** is changed to “Tx Burst mode”.

Please note that:

“Rx – Mode” must first be started in **[Tester]** page.

The DUT is in Tx burst mode. Click **[Stop]** to stop the Tx burst mode.




6.5 Start Rx Burst Mode

In **[Rx – Mode]** sub section, click **[Start]** to let the DUT start receiving burst packets on the specified RF channel (Ch 0 = 2402 MHz).


The **[DUT Status]** is changed to “Rx Burst mode”.

“Tx – Mode” is started on **[Tester]** page.



Click the **[Stop]** button in the **[Rx – Mode]** sub section when the tester has completed sending the number of requested packets.

The **[Received packets]** is updated with the number of packets received by the DUT.



Please note that:

The **[Received packets]** has a maximum depending on the used protocol:

- HCI 65535 packets (wraps around every 40959 ms / ~41 seconds)
- 2-Wire 32767 packets (wraps around every 20479 ms / ~20.5 seconds)


7 Tester Tab

On the **[Tester]** page, you can control the tester manually. This page in conjunction with the **[DUT]** page allow you to run manual tests.

This means that you can start DUT test in Tx or Rx burst mode, e.g. if you start a DUT Tx burst test, you must start a Rx burst test on the **[Tester]** page. The **[Tx - Mode]** and **[Tester Setup - Continuous Wave (CW)]** sections are not available for Advertising Mode.


Overview:

- **[Tester Setup - Burst Mode]** Setup the Tx/Rx test to perform in burst mode.
- **[Tester Setup - Continuous Wave]** Setup the Tx/Rx test to perform in continuous wave mode.
- **[Tester RF Input Power]** Measure the power from the DUT.
- **[Tester Analyzer Mode]** Measure the DUT frequency offset.
- **[Tester Status]** The state of the Tester and reset RF mode and reset Tester, reset Analyzer and Generator options.



7.1 Tester Setup – Burst Mode

In this sub section, you can setup a transmission (Tx) or receive (Rx) test to perform in burst mode.



7.1.1 Tx – Mode

Use the **[Tx – Mode]** sub section to perform a transmit test.

Click **[Start]** to start the transmit test.

Click **[Stop]** to stop the transmit test again.

Please note that:

The **[Tx - Mode]** section is not available for Advertising Mode.

7.1.1.1 Channel

[Current Channel], select the RF channel to use in the test. Valid range 0-39. Refer to section 5.1.3 Select RF Physical Channels for more details.

7.1.1.2 Gen. Power [dBm]

[Gen. Power [dBm]], enter generator power level to use in the test. Valid range -40 to -100 dBm.

Please note that:

The generator power level is not compensated for cable loss.

7.1.1.3 Payload Length

[Payload Length], enter the number of bytes to send as payload in each packet. Valid range between 0-37.

7.1.1.4 Payload Type

[Payload Type], select one of the following BLE payload/packet types, defined by Bluetooth SIG, to use.

Direct Test Mode:

HCI Protocol:

0x00 Pseudo-Random bit sequence 9 (PRBS9)
0x01 Pattern of alternating bits '11110000'
0x02 Pattern of alternating bits '10101010'
0x03 Pseudo-Random bit sequence 15
0x04 Pattern of All '1' bits
0x05 Pattern of All '0' bits
0x06 Pattern of alternating bits '00001111'
0x07 Pattern of alternating bits '0101'

2-Wire Protocol:

0x00 Pseudo-Random bit sequence 9 (PRBS9)
0x01 Pattern of alternating bits '11110000'
0x02 Pattern of alternating bits '10101010'
0x03 Vendor Specific

7.1.1.5 Number of Packets

[No. of Packets], enter the number of packets to send to DUT.

Enter '0' to start a continuous transmission. Click **[Stop]** to stop the transmission.

7.1.1.6 Packets Sent

[Packets Sent], the number of packets that were sent to the DUT.

7.1.2 Rx - Mode

Use the **[Rx - Mode]** sub section to perform a receive test.

Click **[Start]** to start the receive test.

Click **[Stop]** to stop the received test again.

7.1.2.1 Channel

[Channel], select the physical RF channel to use in the test. Valid range 0-39.

Please note that:

For Direct Test Mode all 40 RF channels are supported. For Advertising Mode only channels 0, 12 and 39 should be used. Refer to section 5.1.3 Select RF Physical Channels for more details.

7.1.2.2 Received Packets


[Received Packets], will be updated with the number of packets received when **[Stop]** is pressed.

7.2 Tester Setup – Continuous Wave

In this section, you can setup a transmission (Tx) or receive (Rx) test to perform in CW mode.

Please note that:

The **[Tester Setup – Continuous Wave (CW)]** section is not available for Advertising Mode.



7.2.1 Tx – Mode

Use the **[Tx – Mode]** sub section to perform a transmit test.

Click **[Start]** to start the transmit test.

Click **[Stop]** to stop the transmit test again.

7.2.1.1 Channel

[Channel], select the physical RF channel to use in the test. Valid range 0-39. Refer to section 5.1.3 Select RF Physical Channels for more details.

7.2.1.2 Tx – Set Attenuation

[Tx – Set Attenuation], to set the generator power level send to the DUT.

The attenuator is in one dB steps. Valid range 0 to 93.

0 dB corresponds to –40 dBm generator output power.


60 dB corresponds to –100 dBm generator output power.

Please note that:

Values above 60, equivalent to -100 dBm, are not practically possible and outside specification.

7.3 Tester RF Input Power

In this section, you can measure the RF power on the input. A 'RX Mode', burst or CW must be active to perform this test.




Click **[Read]** to get the measured input power.

As an option, check the **[Monitor]** box to start continuous readings.

7.4 Tester Analyzer Mode

In this section, you can measure the RF frequency offset. A 'RX Mode', burst or CW must be active to perform this test.




Click **[Get]** to read the measured frequency offset.

Click **[Reset]** to reset the frequency offset measurement while running.

As an option, check the **[Monitor]** box to start continuous readings.

7.5 Tester Status

In the **[Tester Status]**, the current state of the RTX2254 tester is shown, i.e. which function has been selected.



7.5.1 Reset RF Mode

Click **[Reset RF Mode]** to reset the application internal mode but not in the RTX2254 tester.

This can be used if the RTX2254 is power cycled and you want to restart the test.

7.5.2 Reset Tester

Click **[Reset Tester]** to send a reset command to the RTX2254 tester to reset its internal state.

Please note that:

It takes some time for the tester to reset and reestablish communication.

7.5.3 Reset Ana+Gen

Click **[Reset Ana+Gen]** to send a reset command to the RTX2254 tester to reset (only) the analyzer and generator internal state.

Please note that:


It takes some time for the tester to reset and reestablish communication.

7.6 Start Tx Burst Mode

In **[Tx – Mode]** sub section, click **[Start]** to let the Tester start transmission of burst on the specified RF channel (Ch 0 = 2402 MHz) using the specified power level, payload length and type. Refer to section

The Tester Status is changed to “Tx Burst mode”. Start **[Rx – Mode]** on **[DUT]** tab.

The Tester is in Tx burst mode. The tester stops when the specified number of packets have been sent.




Please note that:

Specify packet number = 0 for continuous transmission of packets. Click **[Stop]** to stop the Tx burst mode again.

7.7 Start Rx Burst Mode


In **[Rx – Mode]** sub section, click **[Start]** to let the Tester start receiving burst packets on the specified RF channel (Ch 0 = 2402 MHz).

The Tester Status is changed to “**Rx Burst mode**”. Start **[Tx – Mode]** on **[DUT]** tab.



“Tx – Mode” is started on **[DUT]** page to send packets.

Click the **[Stop]** button in **[Rx - Mode]** to get the number of packets sent by the DUT.
 The **[Received packets]** is updated with the number of packets received by the Tester.




Please note that:

The **[Received packets]** has a maximum of 4294967295 packets (unsigned 32 bit).

8 System Tab

On the **[System]** page, you can get information about the RTX2254 tester.



8.1 System Status

[System Status] contains information about the application, supported API version and firmware for the tester board and analyzer board.

Click the **[Get]** button to update the information.

8.2 Manufacture Info

[Manufacture Info] contains production information about the RTX2254, e.g. hardware version, serial number and the installed supported features.

Click the **[Get]** button to update the information.


8.3 System Option License

[System Option License] makes it possible to enter a license number to enable a new feature in the RTX2254 tester. One license enables one new feature.

The license number is entered in the "Enter License" field.

Click the **[Set]** button to set the license. The testers serial number is shown in the "Tester Serial No." field.

The "Enter License" field becomes green if the license is valid:



The screenshot shows a dialog box titled "System Option License". It contains two input fields: "Tester Serial no." with the value "0003" and "Enter License" with the value "1-626VNDQA". The "Enter License" field has a green background. Below the fields is a "Set" button.



A pop-up message is also shown

If the license is invalid or is for another serial number:



The screenshot shows the same "System Option License" dialog box. The "Tester Serial no." field has "0003" and the "Enter License" field has "1-644VNQF". The "Enter License" field has a red background. The "Set" button is visible below.



A pop-up message is also shown

8.4 Internal Temperature

[Internal Temperature] gives information about the tester's internal temperature.

Click the **[Get]** button to update the information.

8.5 Firmware Update

The **[Firmware Update]** sub section allow you to check for new firmware releases for the tester (compared to the already installed firmware) and an option to update the firmware. Follow the **"How to:"** step by step shown.

The firmware can also be manually updated, see chapter 8.6 Manual Firmware Update.

Click **[Check]** button in **[Tester Board]** or **[Analyzer Board]** to check for new firmware delivered with the last installed version of the RTX2254 Bluetooth Tester application.

The firmware file found with the newest version number is shown under **[Firmware file:]** and the currently installed firmware is shown under **[Firmware board:]**:

Firmware Update

Tester Board

Firmware file: **Check**

Firmware board: **Update**

Start Update Application: **Update**

How to: ←

- 1) Click 'Update' to start firmware update
- 2) Make sure that the Portserver is started (Tester status below is green)
- 3) Wait for firmware to download
 - the progress % will be incrementing. Wait for 100% to complete

Analyzer Board

Firmware file: **Check**

Firmware board: **Update**

Start Update Application: **Update**

How to: ←

- 1) Click 'Update' to start firmware update
Wait for firmware applications to start
- 2) Click "Port Settings" and setup the COM-port for the 'Analyzer'
Select Baud=57600, Flow=None, Parity=None,
Stop Bits=One and Data Bits=8
- 3) Click "Select File" and select the new firmware file
E.g. Firmware file: "RTX_BTLE_Analyzer_V<version no.>.bin"
- 4) Click "Erase Image" and then "Load Image"
- 5) Wait for firmware to download and click 'OK'
- 6) Exit RTX BTLE Serial Bootloader

Click **[Update]** to update the firmware.

8.6 Manual Firmware Update

If the firmware does not update automatically it is possible to update the firmware manually, i.e. not using the RTX2254 application.

HWx refers to the hardware version of the tester. Please see the version no. on the label on the back side. V1 is HW1 and V2 is HW2 etc.:

8.6.1 Tester Firmware

How to:

- 'Tester' firmware must be updated to Vxxxx: BtTst_Vxxxx.fwu

The file is located in the folder: .\RTX\RTX2254 Bluetooth RF Tester\Vxxxx\Tools\HWx\Tester\

- Make sure that the Portserver is started and open with the "Tester" COM port active
- Run the "Tester_Stand_Alone_Prog.bat" from firmware location
- Wait for firmware to download

Note! It can be necessary to run the batch file more times due to timing with USB enumeration sync on the PC.

8.6.2 Analyzer Firmware

How to:

- 'Analyzer' firmware must be updated to Vxxxx: RTX_BTLE_Analyzer_Vxxxx.bin

The file is located in the folder: .\RTX\RTX2254 Bluetooth RF Tester\Vxxxx\Tools\HWx\Analyzer\

- Start the tool "RTX BTLE Serial Bootloader.exe" application from firmware location
- Click "Port Settings" and setup the COM-port for the 'Analyzer' interface and select Baud=57600, Flow=None, Parity=None, Stop Bits=One and Data Bits=8
- Click "Select File" and select the file "RTX_BTLE_Analyzer_Vxxxx.bin"
- Click "Erase Image" and then "Load Image"
- Wait for firmware to download and click 'OK'.
- Exit RTX BTLE Serial Bootloader application

9 Measure Logs Tab


On the **[Measure Logs]** page, you can get a log of the tests performed if enabled.

All the test results are also written into the RTX2254 log file. The log file is stored in the folder: "c:\Users\All Users\RTX2254\Log\". This folder can be hidden on some Windows installations.

Log files are named: "RTX2254_Log_Date_<date>_Time_<time of start>.log"

Check the **[Enable Measurement]** box if you wish to save the measurements in the log window and log file.

Click the **[Clear log]** to clear the log screen, i.e. the log file is not erased.



Please note that:

The DUT Bluetooth address is written to log file when **[Start]** is clicked.

Log file example:

```

Lister - [c:\Users\All Users\RTX2254\Log\RTX2254_Log_Date_30-8-2019_Time_2017:38.log]
File Edit Options Encoding Help
RTX2254 Bluetooth RF Tester build date: Tue Aug 27 13:26:40 2019
System sleep periode 1 ms
Log File for saving measurement data.
-----
30.08.2019 20:17:38:989 Log opened
30.08.2019 20:17:39:001 No change in DUT configuration
30.08.2019 20:17:40:288 Tester interface COM ports opened
30.08.2019 20:17:40:685 Tester interface communication opened
30.08.2019 20:17:44:064 No change in DUT configuration
30.08.2019 20:17:45:061 Reset current DUT configuration....
30.08.2019 20:17:45:061 Reset current DUT configuration....
30.08.2019 20:17:49:584 DUT configuration set and stored
30.08.2019 20:17:50:598 Opening new DUT port...
30.08.2019 20:17:51:747 DUT COM port 22 opened
30.08.2019 20:17:51:774 Found DUT with HCI interface, Bluetooth address: 0x84DD20C5038A
30.08.2019 20:17:55:543 No change in DUT configuration
30.08.2019 20:17:57:278 Test setup cleared
30.08.2019 20:17:57:279 Test started by user - click Pause to stop
30.08.2019 20:17:57:288 Testing DUT, Direct Test Mode with HCI protocol, Bluetooth address: 0x84DD20C5038A
30.08.2019 20:17:57:288 Running...
30.08.2019 20:17:59:803 Test no. 1/1 ; Time: 2519.06 ms ; Limit Err.: 0 ; Time Out Err.: 0 ; Ch: 0 ; DUT Offset: 10233 Hz ; 4.26 ppm ; DUT Power: -0.0 dBm ; PER: 0.00 % ; Ok 500 ; Err
30.08.2019 20:18:02:326 Test no. 1/1 ; Time: 2520.52 ms ; Limit Err.: 0 ; Time Out Err.: 0 ; Ch: 19 ; DUT Offset: 9657 Hz ; 4.02 ppm ; DUT Power: -0.7 dBm ; PER: 0.00 % ; Ok 500 ; Err
30.08.2019 20:18:04:248 Test no. 1/1 ; Time: 2521.52 ms ; Limit Err.: 0 ; Time Out Err.: 0 ; Ch: 39 ; DUT Offset: 10299 Hz ; 4.25 ppm ; DUT Power: -1.5 dBm ; PER: 0.00 % ; Ok 500 ; Err
30.08.2019 20:18:04:850 Test PASSED
  
```

Please note that:

The measurements are ';' separated and can be imported to a spread sheet for further analysis.

10 Settings Tab


On the **[Settings]** page, you can setup the communication parameters for the tester and DUT.

The RTX2254 Bluetooth RF tester has 3 main communication interfaces: **[Tester]**, **[Generator]** and **[Analyzer]** which must be opened for the tester to work.

In Direct Test Mode, it must also have an open DUT communication interface to let the RTX2254 Bluetooth RF tester control the DUT.

When the RTX2254 Bluetooth RF tester application is opened it will detect the presence of a connected RTX2254 tester (if option **[Detection @ startup]** is marked). If the RTX2254 tester has been assigned new COM ports, it will prompt the user to accept the new COM port settings or to skip the changes.

Refer to the RTX2254 Quick Installation Guide” for more information about the initial system setup.



[Detect COM Ports] can be used to re-detect the COM ports in the system. You will be asked to accept or skip any new settings.


[Detection @ startup] set mark to enable automatically COM port detection at startup. Unmark to disable this functionality.

Refer to section 10.1 How to find COM ports on Windows for more details.

10.1 How to find COM ports on Windows PC

The COM ports can be found using the Windows "Device Manager".

It can be started from the Windows 'Run' or 'Search programs and files' menu. Type: devmgmt.msc and press <Enter>.



10.2 Tester Interface

The RTX2254 Bluetooth RF tester has 3 main communication interfaces: **[Tester]**, **[Generator]** and **[Analyzer]** which must be opened for the tester to work.

The RTX2254 application should automatically have setup the correct COM port to use. See below how to make changes to the settings if necessary.


10.2.1 Tester - RTX BLE Tester Interface

The **[Tester]** uses the RTX Portserver. In **[Tester interface]**, setup the RTX PortServer COM port to use.

Option:


Setup a specific COM port to use with Portserver or enter 255 to use the manually setup COM port in the RTX Portserver application. Click [Save] to store the settings.

The RTX2254 application must be restarted if the COM port for the RTX Portserver is changed.



Please note that:

The RTX port server can be setup before starting the application (If COM port = 255).



10.2.2 Generator - RTX BLE Generator Interface

Setup the COM-ports for the **[Generator]** interface for your installation.

The **[Auto open]** option can be set (checked) to automatically open the interfaces for Generator and Analyzer when the application is started.

Click **[Save]** to store the settings. The interface must be closed before saving a new value.

Click **[Open]** to open the Generator interface.

Click **[Close]** to close the Generator interface again.

10.2.3 Analyzer - RTX BLE Analyzer Interface

Setup the COM-ports for the **[Analyzer]** interface for your installation.

The **[Auto open]** option can be set (checked) to automatically open the interfaces for Generator and Analyzer when the application is started.

Click **[Save]** to store the settings. The interface must be closed before saving a new value.

Click **[Open]** to open the Analyzer interface.

Click **[Close]** to close the Analyzer interface again.

10.3 DUT interface

The RTX2254 has 2x2 DUT communication interfaces for a dual port version and 1x2 DUT communication interfaces for a single port version:

UART Interface:

- [DUT0 UART]
- [DUT1 UART]

USB Interface:

- [DUT0 USB]
- [DUT1 USB]

Typically, RTX2254 can automatically detect the available COM ports for connected DUTs on a Windows PC.

Please note that:

RTX2254 Bluetooth RF tester can only detect a DUT COM port if the DUT is connected to one of the DUT connectors on the front of the tester.

Furthermore, the DUT must be a "simple" USB device with a virtual COM port (VCP), i.e. the USB device will appear as an additional COM port available on the PC, for it to be automatically detected.


If it is a more complex type with more device types than a COM port it must be manually setup. Refer to section 10.1 How to find COM ports on Windows PC

10.3.1 Automatically Setup of DUT COM ports


Automatically setup of DUT COM port number after the RTX2254 application has been started, e.g. a new DUT is connected or the DUT interface has been changed from UART to USB.

If the DUT COM port is not found, e.g. is it connected to a USB port on the PC, please refer to section 10.3.2 Manually Setup of DUT COM ports.

In example, DUT0 UART is selected and DUT0 COM port 20 and DUT1 COM port 21 were automatically setup at startup:




In example, the **[DUT Port Selection]** on **[Main]** tab are now changed from DUT0 UART to DUT0 USB port.



Click on the **[Detect COM Ports]** button to re-detect the available COM ports.

Please note that

If a COM port is not setup for an interface, it shows -1 as COM port number.




A new DUT0 USB COM port has been found as COM 23.

Click **[Accept]** to set the automatically detected COM port number for DUT0 USB.


Please note that:

Click **[Skip]** to leave with existing COM port settings, i.e. not changes are made to the COM port settings.



The newly found DUT0 USB COM port number is added. Setup the required baud rate and HW flow control for the DUT. Click **[Save]**.


Click **[Open]** in **[DUT Interface]** to open the specified DUT interface.



The DUT interface is now opened and the DUT status is green.


10.3.2 Manually Setup of DUT COM ports

If the DUT COM port cannot be detected, e.g. if it is not connected to the RTX2254 tester it can be setup manually.




In example, find and setup the COM port number for a DUT connected to a USB port on the PC.

In Windows "Device Manager":



The DUT is found as COM port number 30.

Enter the newly found DUT USB COM port number 30 as DUT 0 USB. Setup the required baud rate and HW flow control for the DUT.



Click **[Save]** to store the settings.

Click **[Open]** to open the specified DUT interface.

Please note that:

The active DUT port to open is selected on the **[Main]** or **[DUT]** page.

Click **[Close]** to close the DUT interface again.

In **[DUT interface]**, the current DUT port selected and status with the Bluetooth address of the DUT is shown.

Please note that:

Bluetooth address is only available with HCI protocol.


11 Configuration Tab

On the **[Configuration]** page, you can setup the tester mode, test limits and DUT configurations for Direct Test Mode and Advertising Mode.

[Tester Mode] is used to select either "Direct Test Mode" or "Advertising Mode". "Advertising Mode" requires that the RTX2254 has "Advertising Mode" option installed.

[Test Result Limits] contains the limits for the tests performed on the **[Main]** page, i.e. the valid range the test results must be within for a successful DUT test.

[DUT configuration] contains DUT configuration values for "Direct Test Mode" and "Advertising Mode", e.g. the cable loss and communication protocol.



Please note that:

The default values are the max. limits specified by Bluetooth SIG.

[DUT 1 cable loss (dBm)] will be dimmed for RTX2254 with a single DUT port.

11.1 Test Mode

Select either tester operation mode

- Direct Test Mode
- Advertising

Please note that:

“Advertising Mode” requires that the RTX2254 has “Advertising Mode” option installed.

11.2 Test Result Limits

Setup the limits for a valid test result in **[Test Result Limits]**. If test results are inside these limits the test is marked as “Test PASSED” else “Test FAILED”.

- | | | | |
|----------------------------------------|-------------|-------------|----------|
| ▪ DUT Frequency Offset (ppm) | Valid range | -40 to 40 | ppm |
| ▪ DUT Tx Output Power (dBm) | Valid range | -100 to 50 | dBm |
| ▪ PER – Packet Error Rate (%) | Valid range | 0 | to 100 % |
| ▪ DUT advertising packet interval [ms] | Valid range | 0 to 100000 | ms |

Please note that:

It is for “DUT advertising packet interval [ms]” recommended to set this value a little bit higher than specified for the DUT to handle jitter (0-10 ms), e.g. for 20 ms advertising select min. 25 ms and 100 ms select 110. Adjust this value as required.

The DUT packet interval verification test can be disabled by setting the “DUT advertising packet interval [ms]” maximum limit to 0.

Click **[Save]** to store the results.

11.3 DUT Configuration

[DUT Configuration] setup DUT configuration for “Direct Test Mode” and “Advertising Mode”.

11.3.1 Direct Test Mode

Setup a DUT cable compensation loss, i.e. the signal loss in the cable connected to the front (RF DUT 0 or RF DUT 1) of the RTX2254 tester and the DUT.

The cable loss is a positive value.

- | | | | |
|--------------------------|-------------|-------------|-----|
| ▪ DUT 0 cable loss (dBm) | Valid range | -100 to 100 | dBm |
| ▪ DUT 1 cable loss (dBm) | Valid range | -100 to 100 | dBm |

Please note that:

Only generator power level and test results on the **[Main]** page will be compensated with these values.

Select the DUT communication protocol to use.

- DUT Communication Protocol HCI or 2-Wire

Click **[Save]** to store the results.

11.3.2 Advertising Mode

Setup a DUT cable compensation loss, i.e. the signal loss in the antenna and cable connected to the front (RF DUT 0 or RF DUT 1) of the RTX2254 tester and the DUT.

The cable loss is a positive value.

- DUT 0 cable loss (dBm) Valid range -100 to 100 dBm
- DUT 1 cable loss (dBm) Valid range -100 to 100 dBm

Please note that:

Only generator power level and test results on the **[Main]** page will be compensated with these values.

In the **[Filter Options]** some filter values can be set.

- DUT advertising packet scan interval [ms] Set according to DUT. This value is also used during initial detection/scanning for a new DUT. Make sure that the value is set high enough for the DUT.
- DUT min. power level [dBm] All advertising packets below this value is skipped. Set -127 to get all packets.
- Enable DUT White Listing Enable to filter out advertising packet not coming from the DUT, e.g. the DUT address on the **[Main]** page. If enable, set "Select DUT address type" to either "Public Device Address" or "Random Device Address" according to the DUT specification.

Click **[Save]** to store the results.

12 How to Setup Automated Testing - Direct Test Mode

This chapter describes how you can setup the test parameters for automated testing in Direct Test Mode on the **[Main]** page.


12.1 DUT Test Limits

Go to the **[Configuration]** page to input the DUT test limits and cable compensation. Refer to section 11 Configuration Tab for a detailed description of the parameters.

In **[Tester Mode]** select "Direct Test Mode".

Click **[Save]** to store the values.

For example:



12.2 DUT Test Setup

On the **[Main]** page, you can input the required parameters for your testing.


In **[DUT Port Selection]**, select the correct RF port and DUT interface to use for the test. Then press **[Select]**.

Now check that the 3 status LEDs in the lower, right "Status" frame are green. If not, check **[DUT]** in the **[Open Interface]** box to open the DUT interface.

Enter the RF channels, e.g. 0, 19 and 39 to use in the test in **[Select RF Physical Channels]**.

Check the test boxes for "DUT Frequency Offset", "DUT Tx Output Power" and "PER - Packet Error Rate" in **[Select Tests to Run]** to enable the test in the test run.

Then press **[Save]** to store your settings.



12.3 Starting the DUT Test

This chapter shows two examples of a test run.

The first one is with a DUT fulfilling the test limits and the second one is outside the required testing limits.

Go to the **[Main]** page.

Click **[Start]** in the **[Test Run]** sub section.

The screenshot displays the RTX2254 Bluetooth RF Tester (V0216) software interface. The 'Main' page is active, showing various configuration sections:


- Setup:** Includes 'Measure Mode' (DTM Burst), 'PER Test - Packet Parameters' (No. of Packets: 500, Payload Length: 25, Payload Type: ALTBITS_10101010, Gen. Power: -41 dBm), 'Open Interface' (DUT checked), 'DUT Port Selection' (DUT0 RF Select, DUT0 UART), and 'Settings' (Save button).
- Select RF Physical Channels:** Shows RF Channel 1 (0), RF Channel 2 (19), and RF Channel 3 (39). Channel Mapping table:

Phy	LL	MHz
Ch. 0	(37)	2402
Ch. 1	(0)	2404
Ch. 19	(17)	2440
Ch. 39	(39)	2480
- DUT Info:** BT Address: 0x84DD20C503AA - [ms]
- Select Tests to Run:**
 - DUT Tx Tests:**
 - DUT Frequency Offset: RF Channel 1, 2, 3 (Hz and ppm).
 - DUT Tx Output Power: RF Channel 1, 2, 3 (dBm).
 - DUT Rx Tests:**
 - PER - Packet Error Rate (DTM burst/ADV Mode Only): RF Channel 1, 2, 3 (Error Rate, OK Count, Error Count).
 - Rx Sensitivity Test: RF Channel 1, 2, 3 (Gen. Power Level: -41 dBm).
- Test Result:** A large yellow button labeled 'Start test'.
- Test Run:**
 - Buttons: Start, Stop.
 - Loop Test No.: 1
 - Test Delay [ms]: 0
 - Test Status: Current Channel: 0, Cable Loss: 1.00, Test Completed: 0.
 - DUT packet interval configuration setting [ms]: 1
 - Test Limit Errors: Offset: 0, Tx Pwr: 0, PER: 0, Pkt. Int.: 0.
 - Time Out Errors: 0
 - Ch. Test Time [ms]: Last: 0.00, Avg.: 0.00
 - Total Test Time [s]: 0.000
- Info:** HCI DUT found
- Status:** DUT: HCI 0x84DD20C503AA, Generator & Analyzer: (green), Tester: (green)

12.3.1 DUT - Within Test Limits

In this example, all the tests are within the specified test limits and the DUT passes.

When the test is finished, your screen should look like below:




All tests are within the limits

12.3.2 DUT – Outside of the Test Limits

In this example, the DUT fails on the Tx output power because it is outside of the specified test limit for **[DUT Tx Output Power]**.

A failing test case will be marked red during the test run.

When the test has completed. The overall test status will be red and your screen should look like below:



All Tx power tests are outside the test limits and failed

13 How to Setup Automated Testing - Advertising Mode

This chapter describes how you can setup the test parameters for automated testing in Advertising Mode on the **[Main]** page.


13.1 DUT Test Limits

Go to the **[Configuration]** page to input the DUT test limits and antenna and cable compensation. Refer to section 11 Configuration Tab for a detailed description of the parameters.

In **[Tester Mode]** select "Advertising".

Click **[Save]** to store the values.

For example:



13.2 DUT Test Setup

On the **[Main]** page, you can input the required parameters for your testing.

In the **[PER Test – Packet Parameters]** set the number of packets to use and the payload type. Payload Type is "SCAN_RESPONSE" or "NO_SCAN_RESPONSE".

- **NO_SCAN_RESPONSE** This will scan for advertising packets from the DUT within the specified scan window, e.g. 5 packets every 100 ms => 500 ms scan window. In this time frame it is expected to receive 5 advertising packets.

This packet type only tests DUT Tx.

- **SCAN_RESPONSE** This is basically the same as "NO_SCAN_RESPONSE" but now RTX2254 will for each advertising packet request (scan request) an additional advertising packet from the DUT (scan response). So, by lowering the RTX2254 generator power it is possible to measure the DUT Rx sensitivity (PER test result < 30,7%), i.e. the DUT Rx is also tested.

Please note that:

Some DUTs are only advertisers (beacons) and "SCAN_RESPONSE" cannot be used.

Please note that:

The BLE specification states that advertising has a random delay of 0-10 ms, i.e. for a DUT with advertising interval every 100 ms the "DUT advertising packet interval [ms]" time should be set to 110-120 ms to account for this "jitter". If not, the last advertising packets might fall outside the scanning window. And fail.

In **[DUT Port Selection]**, select the correct RF port and DUT interface to use for the test. Then press **[Select]**.

Now check that the 3 status LEDs in the lower, right "Status" frame are green. If not, check **[DUT]** in the **[Open Interface]** box to open the DUT interface.

The RF channels to use in the test in **[Select RF Physical Channels]** are fixed to channel 0, 12 and 39 in Advertising Mode but they can be enabled (marked) or disabled (unmarked).

Check the test boxes for "DUT Frequency Offset", "DUT Tx Output Power" and "PER – Packet Error Rate" in **[Select Tests to Run]** to enable the test in the test run.

Then press **[Save]** to store your settings.

RTX2254 Bluetooth RF Tester (V0216)

Main Tester System Measure Logs Settings Configuration

Setup

Measure Mode
 ADV Burst

PER Test - Packet Parameters
 No. of Packets: 5
 Payload Type: NO_SCAN_RESPONSE
 Gen. Power [dBm]: -50

Open Interface
 DUT
 Reset DUT

DUT Port Selection
 DUT0 RF Select
 Select

Settings
 Save
 Click "Save" to store setup

Select RF Physical Channels
 RF Channel 1: 0
 RF Channel 2: 12
 RF Channel 3: 39

Channel Mapping:
 Phy LL MHz
 Ch. 0 (37) = 2402
 Ch. 12 (38) = 2426
 Ch. 39 (39) = 2480

DUT Info
 BT Address: 0x84DD20C503AA 107 [ms]

Select Tests to Run

DUT Tx Tests

DUT Frequency Offset

RF Channel 1	RF Channel 2	RF Channel 3
Frequency Offset [Hz]: - Hz	Frequency Offset [Hz]: - Hz	Frequency Offset [Hz]: - Hz
Frequency Offset [ppm]: - ppm	Frequency Offset [ppm]: - ppm	Frequency Offset [ppm]: - ppm

DUT Tx Output Power

RF Channel 1	RF Channel 2	RF Channel 3
- dBm	- dBm	- dBm

DUT Tx Tests

PER - Packet Error Rate (DTM burst/ADV Mode Only)

RF Channel 1	RF Channel 2	RF Channel 3
Error Rate - Measured at Gen. Power [dBm]: - %	Error Rate - Measured at Gen. Power [dBm]: - %	Error Rate - Measured at Gen. Power [dBm]: - %
OK Count: -	OK Count: -	OK Count: -
Error Count: -	Error Count: -	Error Count: -

Rx Sensitivity Test
 Gen. Power Level [dBm]: -50

RF Channel 1	RF Channel 2	RF Channel 3
- dBm	- dBm	- dBm

Average packet interval: -

Test Result

Start test

Test Run

Start Stop Loop Test No.: 1 Test Delay [ms]: 0

Test Status
 Current Channel: 0 Ch. Cable Loss: 1.00 Test Completed: 0
 DUT packet interval configuration setting [ms]: 115

Test Limit Errors
 Offset: 0 Tx Pwr: 0 PER: 0 Pkt. Int.: 0
 Time Out Errors: 0

Ch. Test Time [ms]
 Last: 0.00 Avg.: 0.00 Total Test Time [s]: 0.000

Info Status DUT: Adv 0x84DD20C503AA Generator & Analyzer: Tester:


13.3 Starting the DUT Test

This chapter shows two examples of a test run.

The first one is with a DUT fulfilling the test limits and the second one is outside the required testing limits.

Go to the **[Main]** page.

Click **[Start]** in the **[Test Run]** sub section.




13.3.1 DUT - Within Test Limits

In this example, all the tests are within the specified test limits and the DUT passes.

The **[DUT Info]** shows the DUT Bluetooth address and the average time between the advertising packets from the DUT when DUT interface was opened.

The **[Average packet interval]** shows the average time between the advertising packets from the DUT for the Packet Error Rate test.

When the test is finished, your screen should look like below:




All tests are within the limits

13.3.2 DUT – Outside of the Test Limits

In this example, the DUT fails on the Tx output power because it is outside of the specified test limit for **[DUT Tx Output Power]**.

A failing test case will be marked red during the test run.

When the test has completed. The overall test status will be red, and your screen should look like below:



All Tx power tests are outside the test limits and failed

14 How to Setup Manual Testing

This chapter describes how you can setup the test parameters for manual testing on the [DUT] and [Tester] pages.


14.1 DUT Tab

On the [DUT] page you can control the DUT, i.e. start a radio transmit (Tx) or a receive (Rx) test.

14.1.1 For example, "Test DUT Tx power"

In [Tx - Mode], select the channel, payload length and payload type to use.

Click [Start] to start transmitting. DUT now enters Tx burst mode.



14.2 Tester Tab

On the **[Tester]** page, you can control the tester, i.e. start a radio transmit (Tx) or a receive (Rx) test.


14.2.1 For example, "Test DUT Tx power"

In **[Rx - Mode]**, select the channel (select same channel as set on **[DUT]** page).

Click **[Start]** to start receiving. Tester now enters Rx burst mode.

As an option, in **[Tester RF Input Power]**, check the **[Monitor]** box to start continuous measuring.

As an option, in **[Tester Analyzer Mode]**, check the **[Monitor]** box to start continuous measuring.



Please note that:

The **[Tester RF Input Power]** field is not cable compensated.

15 How to Run a Rx Sensitivity Test

This chapter describes how you can run a DUT Rx sensitivity test. This can be done in "Direct Test Mode" and "Advertising Mode".


Refer to section 12 How to Setup Automated Testing - Direct Test Mode or section 13 How to Setup Automated Testing - Advertising Mode to setup the test conditions. Advertising Mode is used as example.

In **[PER – Packet Error Rate]** enable the **[Rx Sensitivity Test]** to run this test together with the PER test.

Set the no of packet to use in **[No. of Packets]**, packet type in **[Payload Type]** to "SCAN_RESPONSE" (required) and initial generator power is set under **[Gen. Power [dBm]]**.

Please note that:

The DUT must support scan response. DUT advertising packet interval limit errors will be cleared during the Rx sensitivity test. Set limit to 0 to disable limit check.



Test result using Advertising Mode.

The screenshot displays the RTX2254 Bluetooth RF Tester (V0216) software interface. The main window is titled "RTX2254 Bluetooth RF Tester (V0216)" and contains several sections for setup, test configuration, and results.

Setup Section:

- Measure Mode:** ADV Burst
- PER Test - Packet Parameters:** No. of Packets: 10, Payload Type: SCAN_RESPONSE, Gen. Power [dBm]: -70
- Open Interface:** DUT (checked), Reset DUT
- DUT Port Selection:** DUT0 RF Select
- Settings:** Save
- Select RF Physical Channels:** RF Channel 1: 0, RF Channel 2: 12, RF Channel 3: 39
- Channel Mapping:** Ch. 0 (37) = 2402, Ch. 12 (38) = 2426, Ch. 39 (39) = 2480
- DUT Info:** BT Address: 0x84DD20C503AA, 107 [ms]

Select Tests to Run Section:

- DUT Tx Tests:**
 - DUT Frequency Offset:**

RF Channel 1	RF Channel 2	RF Channel 3
2068 Hz	-1553 Hz	3202 Hz
0.86 ppm	-0.65 ppm	1.33 ppm
 - DUT Tx Output Power:**

RF Channel 1	RF Channel 2	RF Channel 3
-1.50 dBm	-2.41 dBm	-3.19 dBm
- DUT Rx Tests:**
 - PER - Packet Error Rate (DTM burst/ADV Mode Only):**

RF Channel 1	RF Channel 2	RF Channel 3
10.00 %	30.00 %	20.00 %
OK Count: 9	OK Count: 7	OK Count: 8
Error Count: 1	Error Count: 3	Error Count: 2
 - Rx Sensitivity Test:** Gen. Power Level [dBm]: -88

RF Channel 1	RF Channel 2	RF Channel 3
-85 dBm	-86 dBm	-88 dBm
 - Average packet interval:**

RF Channel 1	RF Channel 2	RF Channel 3
103 ms	109 ms	100 ms

Test Result Section:

Test PASSED

Test Run Section:

- Start/Stop buttons:** Start, Stop
- Loop Test No.:** 1
- Test Delay [ms]:** 0
- Test Status:** Current Channel: 0 Ch., Cable Loss: 1.00, Test Completed: 1
- DUT packet interval configuration setting [ms]:** 115
- Test Limit Errors:** Offset: 0, Tx Pwr: 0, PER: 0, Pkt. Int.: 0
- Time Out Errors:** 0
- Ch. Test Time [ms]:** Last: 51340.92, Avg.: 46355.71
- Total Test Time [s]:** 139.067

Info Section:

Status: DUT: Adv 0x84DD20C503AA, Generator & Analyzer: (checked), Tester: (checked)

16 Hardware Description

This chapter presents a description of the RTX2254 Bluetooth RF tester hardware, the DUT interfaces and supported protocols.

16.1 Test Interfaces

The RTX2254 Bluetooth RF tester supports one or two DUT interfaces depending on configuration.



RTX2254 Bluetooth RF tester front – Single DUT (RTX no. 95101347)



RTX2254 Bluetooth RF tester front – DUAL DUT (RTX no. 95101348)

16.1.1 DUT RF Inputs

The RTX2254 tester supports up to 2 RF inputs (50 Ω impedance) with N-type connector (dual version). A N-type to SMA converter can be used if using SMA-cables with the tester:

- **RF 0**
- **RF 1** (Dual port only)

16.1.2 DUT Communication Interfaces

The RTX2254 tester supports 2 x 2 DUT interfaces:

- **DUT 0** UART0 and USB0
- **DUT 1** UART1 and USB1 (Dual port only)

UARTx connected through a D-SUB9 connector on the front.


USBx connected through a USB-A connector on the front.

Please note that:

RTX2254 is available as a single ported tester for one DUT (RTX no. 95101347) or as a dual ported tester for two DUTs (RTX no. 95101348).

16.1.2.1 UART0 and UART1 Connector Pinout

The UART0 and UART1 voltage level will auto adjust to the voltage from the connected DUT, i.e. the highest voltage measured on input pins are used. DUT voltages from 1.8V to 5.0V are supported, i.e. an external voltage converter will normally not be required.



UART signals:	D-Sub 9 PIN
Tx	3
Rx	2
CTS	8
RTS	7
Ground	5

Other pins are not connected.

The interface supports the following parameters:

- Baud rate for DUT: 1200, 2400, 9600, 14400, 19200, 38400, 57600, 115200
- Number of data bits: 8
- No parity
- Stop bit: 1
- Flow control (RTS or CTS) enable or disable
- Signal voltages from 1.8V to 5.0V (auto config)


16.1.2.2 2-Wire

2-Wire signals:	D-Sub 9 PIN
Tx	3
Rx	2
Ground	5

The interface supports the following parameters:

- Baud rate for DUT: 1200, 2400, 9600, 14400, 19200, 38400, 57600, 115200
- Number of data bits: 8
- No parity
- Stop bit: 1
- No flow control (RTS or CTS)
- Signal voltages from 1.8V to 5.0V (auto config)

16.1.2.3 USB0 and USB1 Connector Pinout



USB signals:	USB A PIN
VBUS (5V)	1
D-	2
D+	3
Ground	4

16.2 Test Protocols

The RTX2254 Bluetooth RF tester supports the following test protocols:

- HCI Access to the HCI (PHY and LL layer)
- 2-Wire Access to the Non HCI (PHY and LL layer, host/application)

Refer to section 5.1.2.3 Payload Type for the full list of supported packet types.

Please note that:

The tester is transparent for other commands while the RF test commands are not used, i.e. the tester interfaces are not opened by the RTX2254 application.

17 Test Limitations

This chapter describes some testing limitations.

17.1 Generator Output Power

The generator output power when transmitting to the DUT.

The tester can use burst or CW mode in Direct Test Mode. In Advertising Mode is uses the advertising packet type from the DUT.

Main tab:

Parameter	Value
Packets (Burst)	Direct Test Mode: 100 – 65535 Advertising Mode: 1 – 10000
RF level output	-40 to -100 dBm
Frequency (channel)	Direct Test Mode: 2402 to 2480 MHz, 40 channels Advertising Mode: 2402, 2426 & 2480 MHz, 3 channels
Payload pattern	Direct Test Mode: 0 to 7 for HCI 0 to 3 for 2-Wire Advertising Mode: 0 to 1 for Advertising
Payload length	Direct Test Mode: 0-37 bytes Advertising Mode: Advertising packet from DUT

Please note that:

HCI has a receive max. of 64535 packets.
2-Wire has a receive max. of 32767 packets.
Advertising has a receive max. of 64535 packets.

Tester tab:

Please note that:

Advertising Mode not supported

Parameter	Value
Packets (Burst)	0 – 100000 or select 0 for continuous
RF level output	-40 to -100 dBm
Frequency (channel)	2402 MHz to 2480 MHz, 40 channels
Payload pattern	0 to 7 for HCI 0 to 3 for 2-Wire
Payload length	0 to 37

Please note that:

HCI has a receive max. of 64535 packets.
2-Wire has a receive max. of 32767 packets.

17.2 Frequency Offset

The frequency offset is the difference between the RF carrier frequency and the nominal Bluetooth channel frequency.

Main tab:

Parameter	Value
Packets	Direct Test Mode: Min. 740 Advertising Mode: Min. 20
RF level input	-50 to +10 dBm
Frequency (channel)	Direct Test Mode: 2402 to 2480 MHz, 40 channels Advertising Mode: 2402, 2426 & 2480 MHz, 3 channels
Payload pattern	Direct Test Mode: ALT. bits 10101010 (packet type 2) Advertising Mode: Advertising packet from DUT
Payload length	Direct Test Mode: 25 bytes Advertising Mode: Advertising packet from DUT

17.3 PER Test

The PER (Packet Error Rate) test measures the BLE receiver quality.

It is possible to specify the number of packages to send in the PER test and packet type.

Parameter	Value
Packets	0 – 65535
RF level input	-50 to +10 dBm
Frequency (channel)	Direct Test Mode: 2402 to 2480 MHz, 40 channels Advertising Mode: 2402, 2426 & 2480 MHz, 3 channels
Payload pattern	Direct Test Mode: PRBS9 (packet type 0) or selectable: 0 to 7 for HCI 0 to 3 for 2-Wire Advertising Mode: Advertising packet from DUT ¹⁾
Payload length	Direct Test Mode: 37 bytes or selectable 0 to 37 bytes Advertising Mode: Advertising packet from DUT

PER result = 0-100%.

¹⁾ Below the BLE PDU types supported in Advertising Mode:

- **ADV_IND**
Known as Advertising Indications (ADV_IND), where a peripheral device requests connection to any central device.
- **ADV_DIRECT_IND – NOT SUPPORTED**
The connection request is directed at a specific central device.
- **ADV_NONCONN_IND**
A non-connectable device. Advertising information can be received by any listening device.
- **ADV_SCAN_IND**
As ADV_NONCONN_IND, with the option to get additional information via scan responses.

18 Demo Application

This chapter shows some examples of how to use the RTX2254 Bluetooth RF tester with the available demo application "TestProj_RTX2254_BT-Dxxxx.zip".

Please note that:

This is separately delivered. However, updated DLLs and API header files are included in the "Setup_RTX2254_Bluetooth_RF_Tester_Vxxxx.exe" release.

Direct Test Mode and Advertising Mode are supported by the Demo Application (TestProj_RTX2254_BT-D0216.zip).

The demo application has a command line interface. It can be built with Visual Studio 2010, 2013 or 2015.

The Demo Application supports DUT on UART0, UART1, USB0 and USB1.

Refer to the "Readme.txt" for some more details. Please check and update the settings to match your system.

18.1 Settings

Some settings can be customized when building the RTX2254 Demo Application. COM port numbers can be set when executing the Demo Application.

The RTX2254 operation mode: Direct Test Mode or Advertising Mode must be specified at compile time.

DUT_COM is by default UART0_0.

```
// Select the operation mode to use in test
#define USE_DTM_MODE
//#define USE_ADV_MODE

//-----
//--- TESTER choice of number and front port selection


const char    PORTSERVER_NAME[]= "RTX2254PortServer"; // Name of PortServer
                                                       // connected to TESTER
    rsuint16  TESTER_COM      = 10;                // RTX BLE Tester
    rsuint16  GENERATOR_COM   = 11;                // RTX BLE Generator
    rsuint16  ANALYZER_COM    = 12;                // RTX BLE Analyzer
    rsuint16  UART0_COM       = 20;                // UART-0 COM port
    rsuint16  UART1_COM       = 21;                // UART-1 COM port
    rsuint16  USB0_COM        = 22;                // USB-0 COM port
    rsuint16  USB1_COM        = 23;                // USB-1 COM port
const rsbool  DUT_HWExchange  = TRUE;             // DUT uses HW
                                                       // handshake
const int     DUT_BAUD        = 115200;           // Dut Baudrate
    rsuint16  DUT_COM         = UART0_COM;         // Active DUT COM port
    rsbool    DUT_Comm_Open   = FALSE;            // TRUE if DUT communication
                                                       // has been opened
    rsbool    TESTER_Comm_Open = FALSE;           // TRUE if TESTER
                                                       // communication has been opened
```

18.2 Running the Demo Application

You can select the DUT interface to use, i.e. UART0, UART1, USB0 or USB1 by the commands C, D, E, F.

You can map other COM port numbers with the command H

Then you can run one of the test commands, e.g. select 2 to run the "Test PER, Pwr. & Freq. in loop" test.



```

C:\Tmp\TestProj_RTX2254_BT-D0214\Debug\TestProject.exe
+-----+
:   Starting RTX2254 Bluetooth RF TestProject   :
:   SW version: D0214 / 2019.09.30-12:43       :
+-----+

:::=====:::
:::----- Test Project MENU -----:::
:::=====:::
0. EXIT                                     A. Open communication to TESTER
1. Get BD Address                          B. Close communication to TESTER
2. Test PER, Pwr. & Freq. in loop          C. Select UART0 and open communication
3. Get Info from DUT loop                  D. Select UART1 and open communication
4. Getting frequency offset loop           E. Select USB0 and open communication
5.                                         F. Select USB1 and open communication
6.                                         G. Change Loop counter (3)
7.                                         H. Change COM port numbers
8.                                         I. Show COM port numbers
9. Write results to: RTX2254.log           J. Clear all testresults
10.                                        K. Open communication to DUT
11.                                        L. Close communication to DUT
  
```

In the below example, E is selected to use USB0 and then command 2 to run the "Test PER, Pwr. & Freq. in loop" test.

```

C:\Tmp\TestProj_RTX2254_BT-D0214\Debug\TestProject.exe
+-----+
: Starting RTX2254 Bluetooth RF TestProject :
: SW version: D0214 / 2019.09.30-12:43 :
+-----+

:::====----- Test Project MENU -----:::
:::====-----:::
0. EXIT A. Open communication to TESTER
1. Get BD Address B. Close communication to TESTER
2. Test PER, Pwr. & Freq. in loop C. Select UART0 and open communication
3. Get Info from DUT loop D. Select UART1 and open communication
4. Getting frequency offset loop E. Select USB0 and open communication
5. F. Select USB1 and open communication
6. G. Change Loop counter (3)
7. H. Change COM port numbers
8. I. Show COM port numbers
9. Write results to: RTX2254.log J. Clear all testresults
10. K. Open communication to DUT
11. L. Close communication to DUT
E

Port Server open on COM: 10. Status = OK
Open and init connection to TESTER on COM: 10. Status = OK
Waiting 8000 ms for reset of Generator and Analyzer module...
Open and check connection to GENERATOR on COM: 11. Status = OK
Open and check connection to ANALYZER on COM: 12. Status = OK
Enable communication to TESTER. Status = OK
DUT Baudrate = 115200. Status = OK
Open connection to DUT on COM: 22. Status = OK
Opening and checking communication to DUT. Status = OK
Completed opening of communication to COM: 22. Status = OK

:::====----- Test Project MENU -----:::
:::====-----:::
0. EXIT A. Open communication to TESTER
1. Get BD Address B. Close communication to TESTER
2. Test PER, Pwr. & Freq. in loop C. Select UART0 and open communication
3. Get Info from DUT loop D. Select UART1 and open communication
4. Getting frequency offset loop E. Select USB0 and open communication
5. F. Select USB1 and open communication
6. G. Change Loop counter (3)
7. H. Change COM port numbers
8. I. Show COM port numbers
9. Write results to: RTX2254.log J. Clear all testresults
10. K. Open communication to DUT
11. L. Close communication to DUT
2

Analyzer current operation mode 1=Direct Test Mode. Status = OK
Closing the communication to DUT. Status = OK
Close connection to DUT on COM: 22. Status = OK
DUT Baudrate = 115200. Status = OK
Open connection to DUT on COM: 22. Status = OK
Opening and checking communication to DUT. Status = OK
--- Loop no: 1 of 3
Packet error test of 1500 packets on channel 19. Status = OK
TxCount = 1500. Errors = 0. Status = OK
Tester freq offset read Status = OK
Tester freq offset = 10157Hz
Tester measured powerlevel. Status = OK
Tester measured power: -3.79dBm
Tester temperature. Status = OK
Tester temperature = 31C (1294)
--- Loop no: 2 of 3
Packet error test of 1500 packets on channel 19. Status = OK
TxCount = 1500. Errors = 0. Status = OK
Tester freq offset read Status = OK
Tester freq offset = 10137Hz
Tester measured powerlevel. Status = OK
Tester measured power: -3.79dBm
Tester temperature. Status = OK
Tester temperature = 31C (1294)
--- Loop no: 3 of 3
Packet error test of 1500 packets on channel 19. Status = OK
TxCount = 1500. Errors = 0. Status = OK
Tester freq offset read Status = OK
Tester freq offset = 10514Hz
Tester measured powerlevel. Status = OK
Tester measured power: -3.83dBm
Tester temperature. Status = OK
Tester temperature = 31C (1294)
Completed the testloop of PER and Frequency offset. Status = OK

```

19 Frequently Asked Questions

This section presents some frequently asked questions and answers:

- 1) If there is no connection to RTX2254 Bluetooth RF tester**
 - a. Check that USB cable is connected to tester and PC
 - b. Check power cable and that power is ON
 - c. Check power fuse on the back
 - d. Check that the Port Server is started and enabled with the correct COM-port

- 2) If no "Green" status light**
 - a. Check that the COM-port number for Tester, Analyzer and Generator are correct setup, refer to section 10 Settings Tab.

- 3) Tester is not ready – Interfaces not open**
 - a. Check that the COM-port number for Tester, Analyzer and Generator are correct setup, refer to section 10 Settings Tab.
 - b. Check that the COM-port number for the selected DUT interface is correct setup, refer to section 10 Settings Tab.
 - c. Check that the **[Auto open]** box is checked or click **[Open]** to open manually.

- 4) My DUT is not working**
 - a. Check that the COM-port number for DUT, baud rate and selected communication port type (USB/UART) is correct setup, refer to section 10 Settings Tab.
 - b. Check that you have selected the correct communication protocol (HCI or 2-wire) for your DUT.

- 5) Measurements are not in the log file**
 - a. Check that the log feature is enabled on the **[Measure Logs]** page
Refer to section 9 Measure Logs Tab.

- 6) How to see the log files**
 - a. The log files are stored in folder c:\Users\All Users\RTX2254\Log\ and can be opened with a normal text view like Notepad.
Refer to section 9 Measure Logs Tab.

- 7) My settings are not stored**
 - a. Remember to click **[Save]** to store your settings.
If new values are entered and you go to another tab, the old settings will be restored to the last stored when you go back.

- 8) My tester does not show Advertising Mode**
 - a. The Advertising Mode option must be installed with a license.

- 9) My advertising DUT is not detected**
 - a. Make sure that the DUT is advertising. Some BLE devices only have fast advertising interval for the first 30 seconds. Restart advertising.
 - b. Make sure that the "DUT advertising packet scan interval" in "Configuration" tab is high enough. You can set it to maximum 10240 ms. This will increase the detection/scanning time